



Agilent IPCMini Quick Start Guide



Connect HV and AC Power



Select Pump Type



Press & Hold
HV On/Off Switch



