

Vacuum Products Division

UHV-24/UHV-24p Ionization Gauge

INSTRUCTION MANUAL

Manual No. 699905505 Revision F January 2014

UHV-24/UHV-24p Ionization Gauge



Copyright 2014 Agilent, Inc.

Warranty

Products manufactured by Seller are warranted against defects in materials and workmanship for twelve (12) months from date of shipment thereof to Customer, and Seller's liability under valid warranty claims is limited, at the option of Seller, to repair, replace, or refund an equitable portion of the purchase price of the Product. Items expendable in normal use are not covered by this warranty. All warranty replacement or repair of parts shall be limited to equipment malfunctions which, in the sole opinion of Seller, are due or traceable to defects in original materials or workmanship. All obligations of Seller under this warranty replaced in the event of abuse, accident, alteration, misuse, or neglect of the equipment. In-warranty repaired or replaced parts are warranted only for the remaining unexpired portion of the original warranty period applicable to the repaired or replaced parts. After expiration of the applicable warranty period, Customer shall be charged at the then current prices for parts, labor, and transportation.

Reasonable care must be used to avoid hazards. Seller expressly disclaims responsibility for loss or damage caused by use of its Products other than in accordance with proper operating procedures.

Except as stated herein, Seller makes no warranty, express or implied (either in fact or by operation of law), statutory or otherwise; and, except as stated herein, Seller shall have no liability under any warranty, express or implied (either in fact or by operation of law), statutory or otherwise. Statements made by any person, including representatives of Seller, which are inconsistent or in conflict with the terms of this warranty shall not be binding upon Seller unless reduced to writing and approved by an officer of Seller.

Warranty Replacement and Adjustment

All claims under warranty must be made promptly after occurrence of circumstances giving rise thereto, and must be received within the applicable warranty period by Seller or its authorized representative. Such claims should include the Product serial number, the date of shipment, and a full description of the circumstances giving rise to the claim. Before any Products are returned for repair and/or adjustment, written authorization from Seller or its authorized representative for the return and instructions as to how and where these Products should be returned must be obtained. Any Product returned to Seller for examination shall be prepaid via the means of transportation indicated as acceptable by Seller. Seller reserves the right to reject any warranty claim not promptly reported and any warranty claim on any item that has been altered or has been returned by non-acceptable means of transportation. When any Product is returned for examination and inspection, or for any other reason, Customer shall be responsible for all damage resulting from improper packing or handling, and for loss in transit, notwithstanding any defect or non-conformity in the Product. In all cases, Seller has the sole responsibility for determining the cause and nature of failure, and Seller's determination with regard thereto shall be final.

If it is found that Seller's Product has been returned without cause and is still serviceable, Customer will be notified and the Product returned at Customer's expense; in addition, a charge for testing and examination may be made on Products so returned.

3/1/00

This page intentionally left blank.

Contents

Preface	7
Hazard and Safety Information Contacting Agilent	
UHV-24/UHV-24p Ionization Gauge	11
Principles of Operation Installation	
Operating Specifications Maintenance: Filament Replacement	
Appendix A. Gas Correction Factor Table	

This page intentionally left blank.

Preface

Hazard and Safety Information

This product must only be operated and maintained by trained personnel.

This manual uses the following standard safety protocols:



Before operating or servicing equipment, read and thoroughly understand all operation/ maintenance manuals provided by Agilent. Be aware of the hazards associated with this equipment, know how to recognize potentially hazardous conditions, and how to avoid them. Read carefully and strictly observe all cautions and warnings. The consequences of unskilled, improper, or careless operation of the equipment can be serious.

In addition, consult local, state, and national agencies regarding specific requirements and regulations. Address any safety, operation, and/or maintenance questions to your nearest Agilent office.

Grounding the Multi-Gauge and senTorr Controllers

Be certain that your UHV-24/UHV-24p Ion Gauge Controller and vacuum system are separately grounded to a common ground.

WARNING



- Do not place a ground wire between the vacuum chamber and the controller chassis; large continuous currents could flow through it.
- □ Personnel can be killed by high voltages (160 to 900 V may be present in an improperly grounded system).
- □ Make absolutely sure that your vacuum system is grounded as shown in Figure 1.
- □ Test the system ground to be sure that it is complete and capable of supporting at least 10 A.



are not shown.

Figure 1 Ion Gauge and Vacuum System Connections

Use with Combustibles and Mixtures

WARNING



As with all ionization gauges, this device is not intrinsically safe. Exercise extreme care when using this vacuum gauge while pumping or backfilling a system or in any other system condition which contains combustible gases or mixtures. The filament, the end of a hot filament ion gauge and the high voltage discharge of a cold cathode gauge can be ignition sources.

When such a gas or mixture is present, do not turn on any such vacuum gauge. Failure to follow this instruction could result in serious injury to personnel and damage to equipment.

Vacuum Equipment and Cleanliness

Cleanliness is vital when servicing any vacuum equipment.



Do not use silicone oil or silicone grease.

Use powder-free butyl or polycarbonate gloves to prevent skin oils from getting on vacuum surfaces.

Do not clean any aluminum parts with Alconox. Alconox is not compatible with aluminum and will cause damage.



Normally, it is unnecessary to use vacuum grease. However, if it must be used, do not use silicone types, and use it sparingly. Apiezon L grease is recommended (Agilent Part Number 695400004).

Contacting Agilent

In the United States, you can contact Agilent Customer Service at 1-800-882-7426. See the back cover of this manual for a listing of our sales and service offices.

Visit our web site at: http://www.chem.agilent.com/en-US/Products/Instruments/vacuum/pages/default.aspx.

This page intentionally left blank.

UHV-24/UHV-24p Ionization Gauge

The UHV-24 Nude Ionization Gauge, with an x-ray limit of $2x10^{-11}$ Torr, provides reliable pressure measurement from 1 mTorr down to $2x10^{-10}$ Torr, with reduced performance at pressures lower than $2x10^{-10}$ Torr.

The UHV-24p Nude Ionization Gauge utilizes an extremely thin collector which lowers its x-ray limit to 5×10^{-12} Torr. As a result, it can measure pressure from 1m Torr down to 5×10^{-11} Torr, with reduced performance at pressures lower than 5×10^{-11} Torr.

Properly mounted nude gauges, where the grid structure protrudes into the vacuum chamber, offer the lowest error in terms of the local vacuum pressure being the same as the chamber pressure. Both gauges are available with either dual tungsten or thoriated iridium filaments, which are field replaceable.

Nucle gauges are recommended for bakeable, all-metal, ultra-high vacuum systems where maximum exposure to the vacuum gives the highest possible accuracy. The gauges are designed with replaceable dual filament assemblies.

Principles of Operation

The UHV-24/UHV-24p Nude Ionization Gauge contains three elements:

- □ Filament The filament serves as a source of electrons.
- □ Grid The grid functions as the electron collector operating at a positive potential (typically +150 V) with respect to the filament.
- □ Collector wire Along the center of the cylindrical grid structure is a very small diameter ion collector wire operating at a negative potential (typically 28 V) with respect to the filament.

The process is s follows:

- 1. Electrons from the filament pass through the grid several times, on average, before being collected at the grid. While passing through the interior of the grid structure, the electrons ionize gas molecules at a rate which is proportional to the gas density.
- 2. The positive ions produced on the inside of the grid structure are accelerated toward and are neutralized at the collector by electrons from the external circuit. The number of ions produced per electron is proportional to gas density, and the positive ion current to the ion collector is used as an indication of pressure. Thus, for a constant value of accelerating voltage in excess of the ionization potential of the gas, the number of positive ions formed should vary linearly with pressure and with electron current. This is described by the relation:

$$I_c = S \cdot P \cdot I_e$$

where:

 $\hfill\square$ I_c is the ion current in amperes to the collector,

 \Box I_e is the electron current in amperes to the grid, and

D P is the pressure in Torr.

The sensitivity, S, of a given ion gauge is the proportionality constant in the basic ionization gauge equation above. Thus,

$$S = \frac{1}{P} \cdot \frac{I_c}{I_e}$$

For UHV-24 gauges, S for air (nitrogen) is 25 $(\text{Torr})^{-1}$. For the UHV-24p, S for air (Nitrogen) is 20 $(\text{Torr})^{-1}$. The normal operating electron current is 4 mA. For the UHV-24, the ion current at a pressure of 10^{-9} Torr is 10^{-10} A.

Installation

Agilent ionization gauges can be operated with any ion gauge control unit capable of supplying the necessary operating voltages and currents. Degassing of this gauge is by electron bombardment of the grid.

To install the gauge:

- 1. Remove the metal sleeve protecting the collector wire.
- 2. Mount the nude ionization gauges in any position.



Install the gauge in a relatively open space to reduce wall outgassing due to localized heating by the filament. When the gauges are mounted horizontally, position the filaments to the side of the grid rather than below or above it so that a slight vertical movement of the grid or filament does not change their relative spacing.

Operating Specifications

ltem	Requirement		
Filament Voltage	3 to 4.5 V (AC or DC) - Varies with pressure and emission current		
Filament Current	2.5 to 3.5 A - Varies with pressure and emission current		
Element Voltages	Collector voltage: $V_c = 0$		
	Filament voltage: V _{fil} = 28 VDC		
	Grid voltage, V _g = +180 VDC		
Degas Power	Grid Voltage: +600 VDC max		
Requirements (40 W)	Emission Current (total): 67 mA DC		
	Filament Voltage: 7 V		
Measurement	Sensitivity:		
Specifications	25/Torr (UHV-24), nominal		
	20/Torr (UHV-24p), nominal		
	Emission Current:		
	4 mA for widest measurement range 5x10- ¹⁰ Torr to 1x10 ⁻⁴ Torr		
	□ 10 mA for pressures lower than 5×10^{-10} Torr ≤ 0.1 mA for pressure over 1×10^{-4} Torr		
Materials	Filament: Tungsten or thoria-coated Iridium		
	Filament Supports: SST		
	Collector - tungsten:		
	0.007" diameter for UHV-24		
	□ 0.002" for UHV-24p		
	Grid: SST		
	Feedthrough: SST, Alumina, Nickel Alloy		

 Table 1
 Normal Operating Requirements



Figure 2 Typical Gauge Characteristics Graphs

Application Notes

Measurement of ultra-high vacuum is not a trivial undertaking. There are many factors that contribute to measurement problems. Some other concerns include that:

- □ The gauge sensitivity factor is based on nitrogen and very little, if any, nitrogen is present in UHV systems that are leak tight
- □ There are no convenient primary pressure standards that exist for UHV calibration.
- □ A grounded conductive wall near the tube raises the sensitivity by as much as 30%. This is typical of gauges mounted in tubulations attached to the system.

However, these three concerns are usually theoretical in nature and most problems fall under the following areas:

All ion gauges are pumps, (likewise, all ion pumps are gauges). The difference is that gauges are designed primarily to measure pressure and have relatively small pumping speeds. However, given the right conditions it is possible for the gauge to pump the gas that being measured, especially if the chamber pump is small.

Pumping speed for a nude ion gauge is typically around 0.5 litres/sec. The pumping speed is affected by the emission current. The higher the emission current the higher the pumping speed.

- □ Ion gauge out-gassing occurs by virtue of operating the filament. Even after the gauge is *degassed* the filaments continue to generate gas when on. The major component is carbon-monoxide, though other gasses may also be liberated. This gas concentration tends to be higher in the vicinity of the gauge and can lead to higher than expected pressure readings. The hotter the filament, the more it out-gasses. Therefore, to minimize out-gassing use thoriated-iridium filaments, which run significantly cooler than their tungsten counterparts, and run them at the lowest emission current that gives good readings. However, it is necessary to determine if the benefits of the thoriated filaments overcome the drawback of higher particle generation and shorter life when exposed to hydrogen and halogen gases. There is a tradeoff between the gauge pumping and the gauge out-gassing that may compensate one for the other.
- □ Leakage currents are extremely difficult to avoid when using cables of 100 ' or longer. Obviously, the longer the cable the worse the leakage. PTFE is the recommended insulator, but at 5x10⁻¹¹ Torr with a UHV-24p operating with 10 mA of emission current, the ion current is only 10 pA. And that assumes that the gauge sensitivity factor of 20/Torr is somewhat accurate; most likely, it is lower than that. Only rarely is the sensitivity factor higher than expected, such as when mounted in a tubulation. But then the out-gassing and self-pumping issues get worse.
- When cables move, the capacitance between the shield and the conductor changes. This forces a current to flow either into or out of the electrometer circuit, depending upon the change in capacitance. With a long cable the capacitance is fairly large, and because the impedance is very high (the collector is a virtual current source) this current may take quite some time to settle out. Factors that can cause cable to move are:
 - □ Air movement from blowers
 - □ Handling
 - □ Temperature changes

If the cable is in continuous vibration due to running near a pump or other actuator, there may be a continuous current flowing in the collector lead.

Noise pick-up is also made worse by long cable lengths. A shielding system that works fine at 25' may be inadequate at 150'. The cable is an antenna, the longer it is the more signal it picks up. In addition, the ion gauge has wires sticking out into the vacuum chamber, which also act as antennas. However, even if the cable shielding is adequate, noise inside the vacuum chamber is transmitted to the electrometer due to the high source impedance. This causes errors in the measurement as most electrometer amplifiers used in commercial controllers use logging transistors that tend to rectify high frequency noise into DC offsets. Judicious use of ferrite beads on the cable may help.

□ Ground loops can be formed because the chambers are grounded and the controllers are grounded. For safety reasons, never float any controllers that can be touched during operation. Because of the low magnitude of ion currents being measured, it is possible for a ground loop current to overcome the ion gauge signal, sometimes resulting in a current flowing into the gauge collector. This often happens when the ion pumps are running on one phase of the AC power system and the instrumentation is operating off another phase. Experimentation is usually the only answer to find and fix this kind of problem.

Degas

All UHV-24 and UHV24p gauges are operated and degassed at the factory before shipment. Whether to degas the gauge after installation depends upon the application. In large systems that take a long time to pump down, such as several days, or will be baked for an extended period of time, degassing the gauge has a negligible affect. Considering that the e-beam degas system used runs at a high emission current, it may not be worth the theoretical reduction in filament life that results from the small reduction in gas load. In small systems, where the gauge is a larger percentage of the system surface area and gas load, there may be benefits to using degas after installation.Gauge degassing is not generally needed unless the goal is to reach pressures below 1×10^{-8} Torr. Degas is not intended to *clean* tube contamination.

If using degas, a 15 minute e-beam degas duration, using Agilent Multi-Gauge and senTorr controllers, is all that is needed. Extending the degas interval only serves to heat up the surrounding chamber walls and increases the out-gassing rate from those surfaces. Bakeout is a better way to degas the chamber walls.

Bakeout

A temperature of +450 °C is a safe maximum for repeated or extended bakeout of the nude gauge.

Do not:

- □ Exceed +450 °C
- **D** Expose the gauge to thermal shock

Maintenance: Filament Replacement

Agilent's nude gauges are equipped with dual filaments. The filament assembly is easily replaced if it is damaged or broken. The replacement filament kit contains two filament assemblies and an Allen wrench.

Tungsten Filament Replacement

This procedure replace the tungsten filament (Part No. 9710018).

To remove and change the damaged filament:

1. Carefully loosen all six set screws and pull the old filament support brackets out.



Handle the gauge only by its ceramic base to prevent damage to the delicate wires. Wear nylon gloves to prevent placing fingerprints on the gauge. The oil from fingerprints extends pumpdown time.

- 2. Insert the long filament support bracket into its collar so that the filament is located 0.050 to 0.070" from the grid structure.
- 3. Tighten the set screws.
- 4. Insert the short filament support brackets into their collars, pushing them in as far as they will go before tightening the set screws. This ensures proper tension on the filament.

Thoria-Coated Iridium Filament Replacement

This replacement filament kit (Part No. 9710028) contains two thoria-coated iridium filaments stapled to a cardboard backing and packed in a foam-lined plastic box. Each filament also has a stabilizing bar soldered to the base of the filament for rigidity.

To remove and change the damaged filament:

1. Carefully loosen all six set screws and pull the old filament support brackets out.



Handle the gauge only by its ceramic base to prevent damage to the delicate wires. Wear nylon gloves to prevent placing fingerprints on the gauge. The oil from fingerprints extends pumpdown time.

- 2. Carefully remove the stabilizing bar by very carefully cutting between the posts of the thoria-coated iridium filaments.
- 3. Cut the staples affixing the assembly to the cardboard backing.
- 4. Insert the long filament support bracket into its collar so that the filament is located 0.050 to 0.070" from the grid structure.
- 5. Tighten the set screws.
- 6. Insert the short filament support brackets into their collars, pushing them in as far as they will go before tightening the set screws. This ensures proper tension on the filament.
- 7. Carefully trim the remainder of the stabilizing bar from each filament post.

Appendix A. Gas Correction Factor Table

Table 2 on page 20 lists the relative gauge gas correction factors for various gases.

WARNING

Do not assume that the use of the gases listed in this table are safe with hot filament gauge controllers.



The values in *Table 2* are derived by empirical methods substantiated by measurements reported in literature. This table has been compiled and published by Robert L. Summers of Lewis Research Center, NASA Technical Note TND-5285, National Aeronautics and Space Administration, Washington, DC, June 1969.

To automatically convert the UHV-24/UHV-24p readings (normally calibrated for nitrogen):

□ Enter the relative gas correction constant through the front panel key function **F GAS CORR**.

When the gas constant is entered, the gauge divides the result by the gas correction constant and displays the correct adjusted value.

A proper understanding for the transformation of the result is still, however, required. The correction for different gas species is purely mathematical. The tube sensitivity tube is affected by different gases which, in turn, is responsible for the tube output being manipulated by the pressure equation. In addition, There is loss in resolution of the instrument when gas correction constants are used. The loss in resolution becomes more apparent as the correction constants approach 0.5 from either direction. When the correction constants are 0.1 or 10, the tube output is 1/10 or 10 times normal. This causes the instrument to lose the high vacuum decade or the near atmosphere decade, respectively.



Some gases have several correction factors listed. In such cases, the top number is the most commonly-used value.

Substance	Formula	Relative Ionization Gauge Gas Correction Factor
Acetaldehyde	C ₂ H ₄ O	2.6
Acetone	(CH ₃) ₂ CO	3.6
	0/2	4.0
		3.6
Acetylene	C ₂ H ₂	1.9
		2.0
Air		1.0
		0.98
Ammonia	NH ₃	1.3
		1.2
		1.3
Amylene:		
ISO.	ISO C ₅ H ₁₀	5.9
cyclo.	CY·C ₅ H ₁₀	5.8
Argon	Ar	1.3
	\	1.1
		1.2
		0.9
Benzene	C ₆ H ₆	5.9
		5.8
		5.7
		5.9
Benzoic Acid	CeHeCOOH	5.5
Bromine	Br	3.8
Bromomothers		3.0
Bromomethane		3.1
Butane:	- 0.11	
n.	n·C ₄ H ₁₀	4.9
1901	ISO C.H.	4.7
130	130 04110	4.0
Codmium	Cd	1.0
Caumium		2.3
Oashaa Diasid		0.4
Carbon Dioxide		1.4
		1.4
		1.5
		14
		1.4 1.5 1.5 1.4

Table 2 Gas Correction Factor Table

Substance	Formula	Relative Ionization Gauge Gas Correction Factor
Carbon Disulfide	CS ₂	5.0
		4.7
		4.8
Carbon Monoxide	со	1.05
		1.05
Carbon Tetrachloride	CCL	60
	0014	6.3
Cesium	Cs	4.3
		2.0
		4.8
Chlorine	Cl ₂	0.68
		2.6
Chlasshannas		1.0
Chlorobenzene		7.0
Chloroethane	C ₂ H ₅ Cl	4.0
Chloroform	CHCl ₃	4.7
		4.8
Chloromethane	CH.CI	2.6
Chioromethane	011301	3.2
		3.1
Cyanogen	(CN) ₂	2.8
		3.6
		2.7
Cyclohexylene	C ₆ H ₁₂	7.9
		6.4
Deuterium	D ₂	0.35
		0.38
Dichlorodifloromethane	CCI ₂ F ₂	2.7
Dichloromothono		4.1
Dichloromethane		3.7
Dinitrobenzene	$C_6H_4(NO_2)_2$	7.0
m.		7.8
p.		7.6
Ethane	C ₂ H ₆	2.6
	2.0	2.8
		2.5
Ethanol	C ₂ H ₅ OH	3.6
		2.9
Ethyl Acetate	CH ₃ COOC ₂ H ₅	5.0

Substance	Formula	Relative Ionization Gauge Gas Correction F5tor	Substance	Formula	Relative Ionization Gauge Gas Correction Factor
Ethyl ether	(C ₂ H ₅) ₂ O	5.1	Naphthalene	C ₁₀ H ₈	9.7
Ethylene	C ₂ H ₄	2.3	Neon	Ne	0.30
		2.4	Nitrobenzene	CeHeNO2	7.2
		2.2 2.2 to 2.5	Nitrogen	No	1.0
Ethylene oxide	(CH ₂) ₂ O	2.5	Nitrotoluene (o·, m·, p·)	C ₆ H ₄ CH ₂ NO ₂	8.5
Helium	He	0.18	Nitric Oxide	NO	1.3
		0.15 0.13			1.2 1.0
		0.12	Nitrous Oxide	N ₂ O	1.5
Heptane	C ₇ H ₁₆	8.6		-	1.7
Hexadiene: 1.5 [.] cvclo:	1.5·C ₅ H ₁₀	6.4 6.0			1.7 1.3 to 2.1
Hexane	CeH14	6.6	Oxygen	0 ₂	1.0
Hexene:	-0.14				0.9
1.	1 · C ₆ H ₁₂	5.9			0.9
cyclo	CY·C ₆ H ₁₀	6.4	Pentane		2
Hydrogen	H ₂	0.46 0.38	n	n∙C ₅ H ₁₇	6.2 6.0
		0.41			5.7
		0.44	ISO.	$ISO C_5H_{17}$	6.0 5.7
Hydrogen Bromide	HBr	2.0	Phenol		6.2
Hydrogen Chloride	HCI	1.5	Phosphine	PH	2.6
		1.6	Potassium	K	2.0
		2.0	Propano	Calla	3.0
Hydrogen Cyanide	HCN	1.5	Topane	03118	3.7
, , ,		1.6			3.7 to 3.9
Hydrogen Floride	HF	1.4			3.6
Hydrogen lodide	н	3.1	Propene oxide	C ₃ H ₆ O	3.9
Hydrogen Sulfide	H ₂ S	2.2	Propene:	n.C.H.	2.2
		2.2		110316	3.2 to 3.7
		2.1	cyclo.	cy·C ₃ H ₆	3.6
lodine	I ₂	5.4	Rubidum	Rb	4.3
lodomethane	CH ₃ I	4.2	Silver perchlorate	AgCIO ₄	3.6
Isoamyl Alcohol	C ₅ H ₁₁ OH	2.9	Sodium	Na	3.0
Isobutylene	C ₄ H ₈	3.6	Stannic iodide	Snl ₄	6.7
Krypton	Kr	1.9	Sulphur Dioxide	SO ₂	2.1
		1.7			2.3
Lithium	Li	1.9	Sulphur Hexafloride	SF ₆	2.3 2.8
Mercury	Hg	3.6	Toluene	C ₆ H ₅ CH ₃	6.8
Methane	CH ₄	1.4	Trinitrobenzene	C ₆ H ₃ (NO ₂) ₃	9.0
		1.5	Water	H ₂ O	1.1
		1.4 to 1.8		2	1.0
		1.5			0.8
Methanol	CHOOL	1.5	Xenon	Xe	2.9
	01301	1.9			2.2
Mehtyl Acetate	CH ₃ COOCH ₃	4.0	Xvlene:		4.٦
Mythyl ether	(CH ₃) ₂ O	3.0	0.	o·C ₆ H ₄ (CH ₃) ₂	7.8
		3.0	p.	p·C ₆ H ₄ (CH ₃) ₂	7.9

Table B-0 Gas Correction Factor Table (Continued)

This page intentionally left blank.



Vacuum Products Division Instructions for returning products

Dear Customer:

Please follow these instructions whenever one of our products needs to be returned.

- 1) Complete the attached Request for Return form and send it to Agilent Technologies (see below), taking particular care to identify all products that have pumped or been exposed to any toxic or hazardous materials.
- 2) After evaluating the information, Agilent Technologies will provide you with a Return Authorization (RA) number via email or fax, as requested.

Note: Depending on the type of return, a Purchase Order may be required at the time the Request for Return is submitted. We will quote any necessary services (evaluation, repair, special cleaning, eg).

3) Important steps for the shipment of returning product:

- Remove all accessories from the core product (e.g. inlet screens, vent valves).
- Prior to shipment, drain any oils or other liquids, purge or flush all gasses, and wipe off any excess residue.
- If ordering an Advance Exchange product, please use the packaging from the Advance Exchange to return the defective product.
- Seal the product in a plastic bag, and package product carefully to avoid damage in transit. You are responsible for loss or damage in transit.
- Agilent Technologies is not responsible for returning customer provided packaging or containers.
- Clearly label package with RA number. Using the shipping label provided will ensure the proper address and RA number are on the package. Packages shipped to Agilent without a RA clearly written on the outside cannot be accepted and will be returned.
- 4) Return only products for which the RA was issued.
- 5) Product being returned under a RA must be received within 15 business days.
- 6) Ship to the location specified on the printable label, which will be sent, along with the RA number, as soon as we have received all of the required information. Customer is responsible for freight charges on returning product.
- 7) Return shipments must comply with all applicable Shipping Regulations (IATA, DOT, etc.) and carrier requirements.

RETURN THE COMPLETED REQUEST FOR RETURN FORM TO YOUR NEAREST LOCATION:

	EUROPE:		NORTH AMERICA:	PACIFIC RIM:
Fax:	00 39 011 9979 330			
Fax Free:	00 800 345 345 00	Fax:	1 781 860 9252	please visit our website for individual
Toll Free:	00 800 234 234 00	Toll Fr	ee: 800 882 7426, Option 3	office information
<u>vpt-custo</u>	mercare@agilent.com		vpl-ra@agilent.com	http://www.agilent.com



Vacuum Products Division Request for Return Form (Health and Safety Certification)

Please read important policy information on Page 3 that applies to all returns.

1) CUSTOMER INFORMATION

Company Name:		Contact Name:
Tel:	Email:	Fax:
Customer Ship To:		Customer Bill To:
Europe only: VAT reg	. Number:	USA/Canada only: 🔲 Taxable 🗌 Non-taxable

2) PRODUCT IDENTIFICATION

Product Description	Agilent P/N	Agilent S/N	Original Purchasing Reference
			•

3) TYPE OF RETURN (<u>Choose one from each row</u> and supply Purchase Order if requesting a billable service)

3A.	Non-Billable	e 🔄 🔄 Billable	New P0 #	(hard copy must be submit	ted with this forn	n):

3B .	Exchange	Repair	Upgrade	Consignment/Demo	Calibration	Evaluation	Return for Credit
-------------	----------	--------	---------	------------------	-------------	------------	-------------------

4) HEALTH and SAFETY CERTIFICATION

AGILENT TEC RADIOACTIVE Call Agilent T	HNOLOGIES CANNOT ACCEPT ANY PRODUCTS CONTAMINATED WITH BIOLOGICAL OR EXPLOSIVE HAZARDS, E MATERIAL, OR MERCURY AT ITS FACILITY. echnologies to discuss alternatives if this requirement presents a problem.
The equipmen	 It listed above (check one): HAS NOT pumped or been exposed to any toxic or hazardous materials. OR HAS pumped or been exposed to the following toxic or hazardous materials. If this box is checked, the following information must also be filled out. Check boxes for all materials to which product(s) pumped or was exposed:
Toxic	Corrosive Reactive Flammable Explosive Biological Radioactive
List all toxic/	hazardous materials. Include product name, chemical name, and chemical symbol or formula:
NOTE: If a product costs incurred to exposure to toxic	ct is received at Agilent which is contaminated with a toxic or hazardous material that was not disclosed, the customer will be held responsible for all ensure the safe handling of the product, and is liable for any harm or injury to Agilent employees as well as to any third party occurring as a result of or hazardous materials present in the product.
Print Name:	Authorized Signature: Date:
) FAILURE INF	ORMATION:
Failure Mode	(REQUIRED FIELD. See next page for suggestions of failure terms):
Detailed Desc	rintion of Malfunction: (Please provide the error message)

Application (system and model):

I understand and agree to the terms of Sec	ction 6, Page 3/3.	
Print Name:	Authorized Signature:	Date:



Vacuum Products Division Request for Return Form (Health and Safety Certification)

Please use these Failure Mode to describe the concern about the product on Page 2.

TURBO PUMPS and TURBO CONTROLLERS					
APPARENT DEFECT/MALFUNCTION		POSITION		PARAMETERS	
- Does not start	- Noise	- Vertical		Power:	Rotational Speed:
- Does not spin freely	- Vibrations	-Horizontal		Current:	Inlet Pressure:
- Does not reach full speed	-Leak	-Upside-down		Temp 1:	Foreline Pressure:
- Mechanical Contact	-Overtemperature	-Other:		Temp 2:	Purge flow:
- Cooling defective	-Clogging			OPERATING TIME	
ION		VALVES/COMPONENTS			
- Bad feedthrough	- Poor vacuum	- Main seal le		al leak	- Bellows leak
- Vacuum leak	- High voltage problem	- Solenoid fa		failure	- Damaged flange
- Error code on display	- Other	- Damageo		d sealing area	-Other
LEAK DETECTORS			INSTRUMENTS		
- Cannot calibrate	-No zero/high backround -		- Gauge tu	ıbe not working	- Display problem
- Vacuum system unstable	- Cannot reach test mode	- Commu		ication failure	- Degas not working
- Failed to start	- Other	- Error cod		le on display	- Other
SCROLL AND ROTARY VANE PUMPS			DIFFUSION PUMPS		
- Pump doesn't start	- Noisy pump (describe)		- Heater fa	ailure	- Electrical problem
- Doesn't reach vacuum	- Over temperature		- Doesn't	reach vacuum	- Cooling coil damage
- Pump seized	- Other	- Vacuum		leak	- Other

Section 6) ADDITIONAL TERMS

Please read the terms and conditions below as they apply to all returns and are in addition to the Agilent Technologies Vacuum Product Division – Products and Services Terms of Sale.

- Customer is responsible for the freight charges for the returning product. Return shipments must comply with all applicable **Shipping Regulations** (IATA, DOT, etc.) and carrier requirements.
- Customers receiving an Advance Exchange product agree to return the defective, rebuildable part to Agilent Technologies within 15 business days. <u>Failure to do so, or returning a non-rebuildable part (crashed)</u>, will result in an invoice for the <u>non-returned/non-rebuildable part</u>.
- Returns for credit toward the purchase of new or refurbished Products are subject to prior Agilent approval and may incur a restocking fee. Please reference the original purchase order number.
- Units returned for evaluation will be evaluated, and a quote for repair will be issued. If you choose to have the unit repaired, the cost of the evaluation will be deducted from the final repair pricing. A Purchase Order for the final repair price should be issued within 3 weeks of quotation date. Units without a Purchase Order for repair will be returned to the customer, and the evaluation fee will be invoiced.
- A Special Cleaning fee will apply to all exposed products per Section 4 of this document.
- If requesting a calibration service, units must be functionally capable of being calibrated.

This page intentionally left blank.

Service & Support

North America

Agilent Technologies 121 Hartwell Avenue Lexington, MA 02421 USA Tel.: +1 781 861 7200 Toll-Free: +1 800 882 7426 Fax: +1 781 860 5437 vpl-customerservice@agilent.com

Benelux

Agilent Technologies Netherlands B.V. Herculesweg 8 4338 PL Middelburg The Netherlands Tel: +31 118 671570 Fax: +31 118 671569 Toll free: 00 800 234 234 00

China

Agilent Technologies (China) Co. Ltd No.3, Wang Jing Bei Lu, Chao Yang District, Beijing, 100102 China Tel.: +86 (10) 6439 7888 Fax: +86 (10) 6439 1318 Toll-Free: 800 820 8266 vpc-customerservice@agilent.com

France

Agilent Technologies France 7 avenue des Tropiques Z.A. de Courtaboeuf - B.P. 12 91941 Les Ulis cedex France Tel.: +33 (0) 1 69 86 38 84 Fax: +33 (0) 1 69 86 29 88 Toll free: 00 800 234 234 00 vpf.sales@agilent.com

Germany & Austria

Agilent Technologies Lyoner Str. 20 60 528 Frankfurt am Main Germany Tel.: +49 69 6773 43 2230 Fax: +49 69 6773 43 2250 Toll free: 00 800 234 234 00

This information is subject to change without notice.

© Agilent Technologies, Inc., 2012 Published in USA, December, 2012

India

Agilent Technologies India Pvt. Ltd. G01. Prime corporate Park, 230/231, Sahar Road, Opp. Blue Dart Centre, Andheri (East), Mumbai – 400 099. India Tel: +91 22 30648287/8200 Fax: +91 22 30648250 Toll Free: 1800 113037 cag_india@agilent.com

Italy

Agilent Technologies Italia S.p.A. via F.lli Varian 54 10040 Leini, (Torino) ITALY Tel.: +39 011 997 9111 Fax: +39 011 997 9350 Toll-Free: 00 800 234 234 00 vpt.sales@agilent.com vpt-customerservice@agilent.com

Japan

Agilent Technologies Japan, Ltd. 8th Floor, Sumitomo Shibaura Building 4-16-36 Shibaura Minato-ku Tokyo 108 JAPAN Tel.: +81 3 5232 1253 Toll-Free: 0120 655 040 Fax: +81 3 5232 1710 vpj-customerservice@agilent.com

Korea

Agilent Technologies Shinsa 2nd Bldg. 2F 966-5 Daechi-dong Kangnam-gu, Seoul KOREA 135-280 Tel.: +82 2 3452 2455 Toll-Free: 080 222 2452 Fax: +82 2 3452 2451 vpk-customerservice@agilent.com

Singapore

Agilent Technologies Singapore Pte. Ltd No.1 Yishun Avenue 7 Singapore 768923 Tel: +65 6215 8045 Fax: +65 6754 0574 Toll-Free: 1 800 2762622 vps-customerservice@agilent.com

Southeast Asia

Agilent Technologies Sales Sdn Bhd Unit 201, Level 2 uptown 2, 2 Jalan SS21/37, Damansara Uptown 47400 Petaling Jaya, Selangor, Malaysia Tel : +603 7712 6106 Fax: +603 6733 8121 Toll-Free: 1 800 880 805 vps-customerservice@agilent.com

Taiwan

Agilent Technologies Taiwan Limited 20 Kao-Shuang Rd., Pin-Chen City, 324 Taoyuan Hsien, Taiwan, R.O.C. Tel. +886 34959281 Toll Free: 0800 051 342 vpw-customerservice@agilent.com

UK & Ireland

Agilent Technologies 6 Mead Road Oxford Industrial Park Yarnton, Oxford OX5 1QU UK Tel.: +44 (0) 1865 291570 Fax: +44 (0) 1865 291571 Toll free: 00 800 234 234 00 vpt-customerservice@agilent.com

Learn more: www.agilent.com/chem/vacuum

